


ASSEMBLY INSTRUCTIONS
GROUP NO. F1540
DESCRIPTION: DINING CHAIR

Read instruction carefully prior to assembly.


Thank you for purchasing this quality product. Check carefully for small parts which may have come loose during shipment.

Remove all components from pack and place table top upside down on soft surface such as carpet or cloth to prevent scratching the finish. Identify and count all parts as specified below.

Do not tighten bolts until assembly is complete

NO.	HARDWARE PACK		Q'TY	NO.	PARTS LIST		Q'TY
A		ALLEN BOLT ($\varnothing 1/4''*38mm$ L)	2PCS	1		CHAIR BACK	1PC
B		ALLEN BOLT ($\varnothing 1/4''*60mm$ L)	4PCS	2		CUSHION SEAT	1PC
C		ALLEN BOLT ($\varnothing 1/4''*75mm$ L)	4PCS	3		LEG	2PCS
D		LOCK WASHER ($\varnothing 1/4''$)	10PCS				
E		FLAT WASHER ($\varnothing 1/4''$)	10PCS				
F		ALLEN KEY (4MM)	1PC				

STEP: 2



Assembly Completed

Cleaning instructions: Clean using soft cloth

MADE IN VIETNAM