

POUNDEX® BOBKONA® JOYKONA®

PRE-ASSEMBLY TIPS


We get it - building furniture isn't always easy! But have no fear, helpful hints are here. Our assembly tips and tricks will have you enjoying that new furniture in no time. Let's get construction ready to rock!





















POUNDEX® BOBKONA® JOYKONA®

ASSEMBLY SAFETY STEPS




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




POSITIONING

Insert all hardware and parts in the correct holes.




TOOLS

Use hand tools unless the manual specifies power tools.




TIGHTENING

Only tighten bolts when the step is fully completed.



INSTRUCTIONS

Keep the manual and tools for future maintenance needs.



MAINTENANCE

Check for loose joints after 2 weeks and re-tighten every 6 months.

DISCLAIMER:

It is the user's responsibility to properly maintain the furniture over its lifetime. Hardware such as screws, bolts, and other fasteners may naturally loosen over time with normal use of the product. This can lead to instability if the furniture is unable to adequately support the intended weight capacity. To prevent injuries, following the maintenance instructions is key to ensuring product safety and longevity.